

F&M CUSTOM COWLINGS

www.CustomCowlings.com

INSTALL INSTRUCTIONS FOR 496 MAG / MAG HO



1. Remove stock cowl with torx wrench provided.



2. Install spacer assembly with o-ring to keep from losing spacers in engine compartment.

Note: Thread or roll o-ring as close to spacer as possible.



3. Install cowl on motor with hex wrench provided.

4. Stainless steel cowlings only: Peel off PVC, clean edges with lacquer thinner and wax.